

HT-CM
HI-TRAFFIC CARPET MATTING
INSTALLATION INSTRUCTIONS

1. **Adhesive and flooring materials must be stored in a pre-heated building where room temperature is no less than 65 F 24 hours before, during and after installation.**
2. **Subfloor must be cleaned, free of dust, dirt, grease, wax, paint, curing or parting agents or any other substance that may affect the bond. Concrete floors must be level, fully cured, and free of excessive moisture, alkali and hydrostatic pressure.**
3. **Minimum trowel recommendation: carpet tile 1/16 x 1/16 x 1/16, square notch, 150 sq. ft./gallon or spray, brush, or roller application not to exceed 200 sq. ft./gallon; broadloom carpet and cushion 1/16" x 1/16" x 1/16" square notch, 150 sq. ft./gallon.**
4. **Place matting into semi-wet adhesive, and roll using a 35 to 50 pound roller to ensure adequate transfer.**