

BT-220
BERBER TILES

INSTALLATION INSTRUCTIONS

1. **Adhesive and flooring materials must be stored in a pre-heated building where room temperature is no less than 65 F 24 hours before, during and after installation.**
2. **Subfloor must be cleaned, free of dust, dirt, grease, wax, paint, curing or parting agents or any other substance that may affect the bond. Concrete floors must be level, fully cured, and free of excessive moisture, alkali and hydrostatic pressure.**
3. **Minimum trowel recommendation: carpet tile 1/16 x 1/16 x 1/16, square notch, 150 sq. ft./gallon or spray, brush, or roller application not to exceed 200 sq. ft./gallon; broadloom carpet and cushion 1/16" x 1/16" x 1/16" square notch, 150 sq. ft./gallon.**
4. **Allow adhesive to dry completely and turn translucent before proceeding with carpet tile installation. Placing floor covering material into semi-wet adhesive results in a strong, permanent bond, which may be desirable in some installations.**
5. **When using the semi-wet method, roll using a 35 to 50 pound roller to ensure adequate transfer.**