

ALUMINUM RECESS MAT FRAME**INSTALLATION INSTRUCTIONS****1. Frames on hard surfaces:**

In preparation for "monolith" pour, place small batches of concrete under each corner of the frame. Square and make level. After six hours, pour the area within the frame first, and then the entire floor around the frame.

2. Frames on soil base:

As with hard surface installation, follow the same procedure, each corner may be tapped and rods inserted. The rods are then forced into the ground to proper depth, making sure the frame is level and all corners are square.

All corners of the mat frame are accurately mitered. It is not necessary to pound the frame or flute the corner pins to have a tight corner.

Insert two or three anchor keys into each section of the frame. Anchor keys should be located near each corner and within 48" of each other.

Insert the corner pins into the mitered ends of the frame to complete the assembly of the frame.

In setting frame, use screed shelves on the frame for accurate troweling to the required sub-floor levels.

After cement has set, fill the frame recess with 1/2" plywood (or boards) to protect frame until mats are installed.

