

Vinyl Tile

INSTALLATION

Surface Preparation- Subfloor (wood or concrete) must be structurally sound, clean, smooth, dry free from dust, dirt, wax, grease, and/or any other foreign material that would interfere with a good bond. **DO NOT USE** adhesives where moisture is present in concrete or wood-type subfloors. Moisture may retard or prevent adhesive from setting.

Primer-the latex primer acts like a sealer but allows adhesion of the planks to the concrete floors. It also helps preventing moisture from getting between the planks and subfloor.

Tools required – You will need a utility knife, carpenter square, chalk, string, pencil and rolling pin.

INSTALLATION GUIDE

Planks and adhesive must be conditioned at room temperature, minimum 65°F for 24 hours before and 24 hours after installation. Spread adhesive with a 1/16" X 1/16" X 1/16" square-notch trowel. Apply adhesive to subfloor according to the instructions on the container. Spread adhesives to small areas to avoid letting the adhesive dry too much before you have finished laying your plank. For planks use the wet set installation instructions. Roll each section immediately upon completing with a 100 pound three-section roller. Re-roll the entire floor after one or two hours. If you do not have access to a roller, then use a rolling pin and your body weight. Do not wash or treat the floor for a minimum of 48 hours after installation.